BELLWETHER OWNERS

> Unofficial owner resource. Not affiliated with, endorsed by, or sponsored by Bellwether Coffee Co. “Bellwether” is their trademark, used here only to identify the machines. Articles below are reproduced from Bellwether’s public help center. © Bellwether Coffee Co.

Bean load, drop and cooling tray

Public articles that touch the bean path. Series 2 alarm names such as bean exit and bean load are not explained in the logged-out help center.


Shop Roaster: Lubricating The Bean Drop Slide Door

Source: Bellwether Coffee, https://help.bellwethercoffee.com/shop-roaster-bean-drop-slide-door-lubrication. Reproduced for owners; © Bellwether Coffee Co.

Source: Bellwether Coffee, original article. Reproduced for owners; © Bellwether Coffee Co.

This process will help extend the life of the parts associated with the Bean Drop Slide Door.

Follow this link to the article: LINK



Source: Bellwether Coffee, original article. Reproduced for owners; © Bellwether Coffee Co.



Source: Bellwether Coffee, original article. Reproduced for owners; © Bellwether Coffee Co.